



THE UNIVERSITY OF ARIZONA
GRADUATE COLLEGE

Undergraduate Research Opportunities Consortium


Optical Characterization of Gallium Arsenide Quantum Dots

Author Names: Casey A. Timms, Chloe I. Marzano, John R. Schaibley (University of Arizona)
Sadhvikas J. Addamane (Sandia National Laboratories)

Program Affiliation: The University of Arizona, UROC Summer Research Institute Program




Background




- An excitation laser can be used to move a two-level system to an excited state.
 - When this occurs, an electron-hole pair is formed.
 - The electron occupies the conduction band, and the hole occupies the valence band.
 - The system quickly decays back to the ground state releasing its stored energy as a photon.
 - Photons formed in this way are called exciton emissions.
 - An important first step for optical characterization of quantum dots is photoluminescence spectroscopy (PL).
 - This technique measures the energies of emitted photons, and allows us to select suitable samples for future measurements.
- Gallium Arsenide (GaAs) Quantum Dots are semiconductor devices made using GaAs and Aluminum Gallium Arsenide (AlGaAs).
 - The band gap difference between the AlGaAs and GaAs creates low-energy, trapped electron states.
 - These states are similar to two-level systems allowing for the creation of single photons.

Device Design




- 500 nm of AlGaAs, made up of 0.7 Aluminium (Al) and 0.3 Gallium (Ga), was grown on a GaAs substrate and capped by a 5 nm layer of GaAs.
- A 140 nm AlGaAs layer, made up of 0.4 Al and 0.6 Ga, was grown on the GaAs cap.
- Al droplets were deposited on the device, and Arsenic (As) droplets were sprayed onto the Al.
- As a result, small holes, called nanoholes were drilled. These nanoholes were filled with a 5 nm top layer of GaAs, creating GaAs quantum dots.
- Varying growth conditions changed the energies of photons emitted by the quantum dots.
- All samples were fabricated at Sandia National Laboratories by Sadhvikas Addamane

Optical Setup



- Samples were held at 9 K in a helium cryostat and were excited by a red (633 nm) laser.
- The laser was passed through a 700 nm short pass filter before reaching and exciting the sample.
- The excitation signal and reflected laser were directed by a beam splitter through a 650 nm long pass filter, which blocked the reflected laser light.
- The signal passed through the filter and into a spectrometer, which used a charge coupled device (CCD) camera to measure the emission energies.


Photoluminescence Spectrum From Single Quantum Dot




- A photoluminescence spectrum taken from a single quantum dot.
- The high intensity peak centered at 1.64 eV corresponds to the quantum well created by the 5 nm GaAs layer.
- The lower intensity peaks with lower energy are emissions from the quantum dot.

Future Directions

- The immediate next step is to perform an antibunching measurements on quantum dots from sample 9 to determine if these quantum dots emit a single photon per excitation cycle.
- These measurements employ a similar optical setup to photoluminescence measurements, but after reaching the spectrometer, emissions from quantum dots are split into two time correlated single photon detectors.
- If the probability of both detectors firing at the same time is measured to be 0, then these quantum dots are single photon emitters.
- After antibunching measurements are successfully performed, we can move to measuring other optical phenomena such as Rabi oscillations or the Hong-Oh-Mandel effect.




Emission Peaks



- Photoluminescence data was collected from several quantum dots across two samples: sample 8 and sample 9.
- Exciton emissions were identified as high intensity peaks, labeled X. Lower intensity peaks correspond to charged exciton emissions.
- Sample 8 had exciton emissions with an average energy of 1.6323 ± 0.0032 eV, and Sample 9 had exciton emissions with an average energy of 1.6267 ± 0.0016 eV.

Conclusions

- Sample 9 hosted quantum dots whose exciton emissions had significantly lower energy than those of sample 8.
- This means that the emissions from quantum dots on sample 9 are separated from the high intensity quantum well.
- Therefore, future measurements should be performed on these quantum dots.



Acknowledgements

- John Schaibley, Ph.D.: Research Mentor
- Chloe Marzano; Sadhvikas Addamane, Ph.D.: Project Collaborators
- Pritam Bangal, M.S.; Sean Driskill; Trevor Stanfill: Lab Staff
- Tianna MacMeans: Program Coordinator
- Leah Callovini, M.S.; Melinda Struyk, M.A.: Instructors
- Kirsten Limesand, Ph.D.: Dean of the Graduate College
- Frans Tax, Ph.D.: Associate Dean of Student Affairs and Diversity & Inclusion
- Donna Treloar, M.A.: UROC Director

